Product info sheet: glimtrex[®] Remover



Product description

Heavy duty cleaner for removing stubborn dirt, stains, and light scratches from wooden floors.

Characteristics

- A highly effective, water-based cleaning solution for removing old care products from sealed parquet and wooden floors
- Easy to use
- Not suitable for mirrors, marble or non-slip surfaces
- Water based

Instruction

- Glimtrex[®] Remover is diluted with water according to the degree of soiling. The surface should be wiped evenly with a damp cloth
- Initial cleaning: approximately 1 L of glimtrex[®] Remover to 5 L of cleaning water
- Mop the floor with the cleaning solution and leave to penetrate for 5 minutes. (The application quantity and penetration time should be gauged so that no swelling occurs in the wood).
- Mop the surface again with clean water to remove the dissolved coating and any potential remover residue. (Make sure that the surface does not get too wet during mopping).
- It could alternatively be used on a buffing machine with a white pad to remove the dirt completely. After drying it is necessary to maintain the floor with glimtrex[®] Intensive-Care or glimtrex[®] Wax-Polish.
- The area should be absolutely dry before to maintain.

Hints

For large surfaces it is recommended to divide the surface into sections. The suitability of the surface for the use of glimtrex[®] Remover should be tested in a small location before full application.

The cleaning effect for specific contaminants should also be tested.

Experience suggests stains that are already present on the existing surface of the coating, or that have already infiltrated into the wood can no longer be completely removed by the subsequent cleaning and maintenance.



Yield per litre

- Lighter cleaning
- Medium cleaning
- Heavy cleaning

up to 60m² up to 35m² up to 20m²

Technical information

Available in 1 and 5 litre cans.

The shelf life is minimum 24 months in the closed original tin. Make sure to stir the tin thoroughly before using.

Please look at the current safety data sheets. You will find them at www.glimtrex.de/downloads.

This information is purely advisory and is based on the best knowledge available through careful research. This information cannot be held as legally binding.

Tel.: Fax: E-Mail: Internet: