Product info sheet:

glimtrex® SIGNUM Intensive-Care



Product description

Care product suitable for the revitalizing of all lacquered wood-surfaces. Suitable for all surfaces that are treated with 1-component- or 2-component-laquers.

Characteristics

- · Freshens old and unsightly surfaces
- Reduces wear and tear
- vegan
- Easy to use

Instructions

- Remove loose dirt with a vacuum cleaner or fine broom
- Wash the floor using glimtrex® SIGNUM Floor-Care as per instructions
- Wipe the surface and allow to dry properly
- Very dirty or damaged floors should be cleaned with glimtrex® Remover.
- Allow surface to dry thoroughly
- Apply glimtrex[®] SIGNUM Intensive-Care evenly over the whole floor by using a lint free cloth or fibre mop
- Ensure that the whole surface is well covered
- Where possible, finish in the direction of the grain

For large surfaces, it is recommended to divide the surface into sections.

Do not wipe in already dry[ing] areas as there is a risk of streaking.

When damp, avoid draughts and the movement of dust. Older surfaces or parquet finishes may have issues with glimtrex® SIGNUM Intensive-Care adhering due to possible existing finishes/coatings. Therefore, always test a sample area if possible and assess whether the result meets your requirements.

Test the bonding between all coats.

At regular intervals, old glimtrex[®] SIGNUM Intensive-Care residues should be removed from the surface by using glimtrex[®] Remover.

Tel.:

Fax:

+49 (0) 2504-88887-111

+49 (0) 2504-88887-112

e-mail: info@glimtrex.de

Internet: www.glimtrex.de



Yield per litre

Lighter cleaning up to 45m²
Medium cleaning up to 30m²
Heavy cleaning up to 15m²

Technical information

Available in 1 and 5 litre cans.

The shelf life is minimum 24 months in the closed original tin. Make sure to stir the tin thoroughly before using.

Please look at the current safety data sheets. You will find them at www.glimtrex.de/downloads.

This information is purely advisory and is based on the best knowledge available through careful research. This information cannot be held as legally binding.

Tel.:

Fax:

+49 (0) 2504-88887-111

+49 (0) 2504-88887-112

e-mail: info@glimtrex.de

Internet: www.glimtrex.de